



Dirt Devil Infinity VS8 Turbo Disassembly

How to remove main panel from Dirt Devil VS8 vacuum cleaner to get access to engine.

Written By: MarW



Step 1 — Dirt Devil Infinity VS8 Turbo Disassembly



- Remove 4 screws on the bottom side using Philips screwdriver

Step 2




- Remove 2 buttons by levering them using slot screwdriver.
- Remove 2 screws

Step 3



- Remove last spanner screw, maybe you can do it using spanner head (pig nose) screwdriver.
- I have made special key to turn it using piece of 1mm wire and screw.

Step 4



- Now you can see how it looks inside, get access to engine or cable roller.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-18 03:34:44 AM.